

CAP-OFF

Installation Instructions!

1. Remove supplied contents from shipping package.
2. Locate from the four corners, the center area of your battery.
3. Choose one of the most central plastic buss bar covers on the top of the battery.
4. Slide the supplied plastic tie wrap under one of the plastic buss bar covers to approximately half way with its V shape facing upwards.
5. Slide the loop at the loose end of the Cap-Off tether cord over the tapered end of the plastic tie wrap.
6. Insert the tapered end of the plastic tie wrap into the flat side of the self locking receiver at the opposite end of the tie wrap.
7. Pull the tapered end of the tie wrap until it is snug around one of the center buss bar covers.
8. Then using snips cut the excess tie wrap off and dispose of this piece appropriately.

